

24/7 ASSET MONITORING SOLUTION


HTR02 USER MANUAL**SENSeOR (head office)**

Bâtiment Natura 2
1198, avenue du Docteur
Maurice Donat
06250 Mougins
France

ISO 9001:2015

BUREAU VERITAS
Certification

Contact address:

support.senseor@wika.com**Regional distributors**

Visit www.senseor.com for
the latest distribution
locations.



WARRANTY

These products are warranted to be free from functional defects in material and in workmanship at the time of the manufacturing and to conform at that time to the specifications set forth in the relevant instruction manuals or in the data sheets, for such products for a period of one year.

Reference SENSEOR terms and conditions provided at time of purchase for complete warranty details.



SENSeOR (head office)

Bâtiment Natura 2

1198, avenue du Docteur Maurice Donat,

06250 Mougins

France

SENSeOR reserves the right to make technical changes or to modify the content of this document without prior notice.

SENSeOR is not responsible for errors or for possible lack of information in this document.

All rights reserved. No part of this document may be reproduced, distributed, or transmitted in any form or by any means, including photocopying, recording, or other electronic or mechanical methods, without the prior written permission of SENSEOR, except in the case of brief quotations embodied in critical reviews and certain other non-commercial uses permitted by copyright law.

Copyright © 2023, SENSEOR

TABLE OF CONTENTS

- WARRANTY 2
- TABLE OF CONTENTS 3
- SAFETY INSTRUCTIONS 5
 - 1.0 CONVENTIONS..... 5
 - 1.1 SAFETY INFORMATIONS 6
- OVERVIEW 7
 - 1.0 RELATED DOCUMENTS 7
 - 1.1 AVAILABLE PRODUCTS..... 7
 - 1.2 INSTRUCTIONS FOR USE 8
 - 1.3 READER OVERVIEW 9
 - 1.3.1 SERIALIZATION LABEL 9
 - 1.3.2 FRONT LABEL 9
 - 1.4 CONNECTORS AND FUNCTIONS 10
 - 1.4.1 INPUT POWER (MAIN CONNECTOR) 10
 - 1.4.2 RS485 PORTS 11
 - 1.4.3 ENVIRONMENTAL SENSOR 11
 - 1.4.4 ANALOG INPUTS/OUTPUTS (FRONT SELF-TIGHTENING CONNECTOR) 12
 - 1.4.5 RF ANTENNAS 12
 - 1.5 STATUS LED..... 13
- INSTALLATION 14
 - 1.6 UNPACKING 15
 - 1.6.1 PHYSICAL DIMENSIONS 15
 - 1.7 DIN RAIL MOUNTING..... 16
 - 1.7.1 READER EMPLACEMENT..... 17
 - 1.7.2 RECOMMENDED SPACING..... 17
- WIRING 18
 - 1.8 POWER..... 18
 - 1.8.1 INPUT POWER..... 18
 - 1.8.2 INTERNAL BATTERY 19
 - 1.9 COMMUNICATION CONNECTIONS..... 20
 - 1.9.1 CABLING FOR RS485 COMMUNICATION 20
 - 1.9.2 BUS RESISTIVE TERMINATION 20
 - 1.9.3 BUS DATA RATE 21
 - 1.9.4 BUS LENGTH 21

- 1.9.5 NUMBER OF READERS 21
- 1.9.6 MODBUS-RTU DEFAULT CONFIGURATION..... 21
- 1.9.7 CABLING FOR ETHERNET COMMUNICATION 22
- 1.10 ENVIRONMENTAL SENSOR CONNECTION 23
- SYSTEM INSTALLATION & CONFIGURATION 24
- 1.11 SAW TEMPERATURE SENSORS INSTALLATION 24
- 1.12 SYSTEM CONFIGURATION 24
- SYSTEM INTEGRATION 25
- 1.13 MODBUS REGISTERS..... 25
- CERTIFICATIONS 30
- 1.14 CERTIFICATIONS 30
- 1.15 MARKING 30



SAFETY INSTRUCTIONS

IT IS IMPORTANT TO READ THIS MANUAL BEFORE INSTALLING OR COMMISSIONING SENSEOR ASSETS MONITORING SYSTEM.

1.0 CONVENTIONS

DANGER

DANGER INDICATES AN IMMINENTLY HAZARDOUS SITUATION, WHICH, IF NOT AVOIDED, WILL RESULT IN DEATH OR SERIOUS INJURY.

FAILURE TO FOLLOW THE INSTRUCTIONS GIVEN WILL RESULT IN DEATH OR SERIOUS INJURY.

WARNING

WARNING INDICATES A POTENTIALLY HAZARDOUS SITUATION, WHICH, IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY.

FAILURE TO FOLLOW THE GIVEN INSTRUCTIONS CAN RESULT IN DEATH OR IN SERIOUS INJURY.

CAUTION

CAUTION INDICATES A POTENTIALLY HAZARDOUS SITUATION, WHICH, IF NOT AVOIDED, MAY RESULT IN MINOR OR MODERATE INJURY.

FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PERSONAL INJURY.

NOTICE

NOTICE PROVIDES GUIDANCE ON DAMAGE UNRELATED TO PERSONAL INJURY, SUCH AS THOSE THAT CAN CAUSE DETERIORATED PROPERTY.

FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PROPERTY DAMAGE.

IMPORTANT

IMPORTANT INDICATES ADDITIONAL INFORMATION ABOUT MAKING EFFECTIVE USE OF THIS PRODUCT.

1.1 SAFETY INFORMATIONS

- ▶ Protect product from moisture and humidity.
- ▶ Protect product from too high or too low temperature.
- ▶ Protect product from fire.
- ▶ Do not paint the product.
- ▶ Do not modify or disassemble the product. Service must be carried out by *SENSeOR*.
- ▶ Store products in dry and dust-free place.

OVERVIEW

CAUTION

THIS READER IS DEDICATED TO SWITCHGEAR MONITORING WITH WIRELESS PASSIVE SAW TEMPERATURE SENSORS, ENVIRONMENTAL SENSOR AND UHF PARTIAL DISCHARGE DETECTION. IT IS DESIGNED FOR USE INSIDE METALLIC CAVITIES ONLY LIKE THE SWITCHGEAR CABINET AND TUNED TO BE COMPLIANT WITH IEC 62271 ENABLING A LICENSE-FREE USE IN SWITCHGEAR WORLDWIDE.

1.0 RELATED DOCUMENTS

- UM00013EN-AG: SENSEOR Configuration Tool for HTR02 User Manual.
- SD00184EN-AC: HTR02 readers Datasheet.

For additional related documentation and file downloads see support website at senseor.com/downloads.

1.1 AVAILABLE PRODUCTS

This manual covers the following products:

- **HTR02-2AWS**: Temperature monitoring only.
- **HTR02-6AWS**: Temperature monitoring only.
- **HTR02-6AWS-PDD**: Temperature & partial discharge monitoring.

1.2 INSTRUCTIONS FOR USE

The HTR02 reader is dedicated to monitor electrical equipment like switchgears. The temperature of live conductors is measured by SAW sensors and prevent overheating and overload. Partial discharges are measured by antenna pairs and prevent equipment failure. Ambient temperature and humidity measurements are also available through an optional [environmental sensor](#) connected with wires to the reader.

The reader is intended to be installed in low voltage compartments of switchgear or in similar type of assets. It can also be installed in a weatherproof environmental enclosure.

The reader is intended for use at a maximum altitude of *5 km*, typically between -20°C to $+70^{\circ}\text{C}$ (refer to reader specification for the complete specification) and between *10%* to *95%* non-condensing relative humidity.

WARNING

THE READER IS NOT INTENDED FOR INSTALLATION INTO MEDIUM OR HIGH VOLTAGE COMPARTMENT ASSETS. ONLY SAW TEMPERATURE SENSORS, ENVIRONMENTAL SENSOR AND RF ANTENNAS ARE INTENDED FOR INSTALLATION INTO MEDIUM VOLTAGE COMPARTMENTS.

1.3 READER OVERVIEW

Included in scope of delivery:

- 1x HTR02 reader.
- 1x µSD card.
- 1x 4-pin power connector.
- 1x 4-pin environmental sensor connector (for HTR02-6AWS readers).

1.3.1 SERIALIZATION LABEL




Figure 1: HTR02-6AWS-PDD reader serialization label

1.3.2 FRONT LABEL




Figure 2: HTR02-2AWS front product label






Figure 3: HTR02-6AWS front product label

1.4 CONNECTORS AND FUNCTIONS



1.4.1 INPUT POWER (MAIN CONNECTOR)

Pin	Type	Description
1 (left)	GND SUPPLY	Ground
2	GND	Ground (not used)
3	+24VDC	Main power supply input
4 (right)	GND	Ground (not used)



CAUTION

DO NOT REVERSE THE POWER SUPPLY POLARITY, THIS MAY CAUSE ELECTRICAL DAMAGE.

1.4.2 RS485 PORTS

RJ45 ports for Modbus-RTU communication.

Pin	Type	Description
1 (left)	-	Not used
2	-	Not used
3	-	Not used
4	A	Data +
5	B	Data -
6	-	Not used
7	-	Not used
8 (right)	GND	Ground




Figure 4: RS485 socket pinout

1.4.3 ENVIRONMENTAL SENSOR

Pin	Type	Description
1 (left)	TEMP IN	4–20 mA input for temperature sensor
2	HUM IN	4–20 mA input for humidity sensor
3	GND	Ground
4 (right)	GND	Ground




Figure 5: Environmental sensor socket pinout

NOTE

THIS CONNECTOR IS ONLY AVAILABLE FOR HTR02-6AWS-PDD READERS.

1.4.4 ANALOG INPUTS/OUTPUTS (FRONT SELF-TIGHTENING CONNECTOR)

Pin	Type	Description
1 (top)	TRIG OUT	Alarm relay activation output
2	I IN	4–20 mA input
3	SYNC IN	Digital input
4	I OUT	4–20 mA output
5 (bottom)	V OUT	0–10V output




Figure 6: Analog I/Os socket pinout

1.4.5 RF ANTENNAS

Connector	Type	Description
1A	1A	RF antenna 1A
1B	1B	RF antenna 1B
2A	2A	RF antenna 2A (only for HTR02-6AWS)
2B	2B	RF antenna 2B (only for HTR02-6AWS)
3A	3A	RF antenna 3A (only for HTR02-6AWS)
3B	3B	RF antenna 3B (only for HTR02-6AWS)




Figure 7: RF antennas

1.5 STATUS LED

Status LED is used to indicate the functional state of reader.

Description	LED status
No power	[Grey bar]
Installation mode	[10 Blue LEDs]
Configuration mode	[10 Green LEDs]
Measure mode (SAW & partial discharge)	[10 Green LEDs]
SAW measurements demonstration mode	[10 Blue LEDs]
PDD measurements demonstration mode	[10 Purple LEDs]
Warning threshold reached	[10 Yellow LEDs]
Alert threshold reached	[10 Red LEDs]
System error	[Red bar]




Figure 8: Status led

INSTALLATION

IMPORTANT

THE INSTALLATION INSTRUCTIONS ARE ONLY FOR THE HTR02 READER.

IT IS ASSUMED THAT SAW TEMPERATURE SENSORS AND PARTIAL DISCHARGE PROBE ANTENNAS HAVE BEEN CONFIGURED AND INSTALLED.

WARNING

PROFESSIONAL INSTALLATION REQUIRED.

INSTALLATION AND CONFIGURATION SHOULD BE PERFORMED ONLY BY USERS WHO ARE TECHNICALLY COMPETENT AND AUTHORIZED TO DO SO.

LOCAL REGULATIONS REGARDING ELECTRICAL INSTALLATION AND SAFETY MUST BE OBSERVED.

FAILURE TO FOLLOW THE GIVEN INSTRUCTIONS CAN RESULT IN DEATH OR IN SERIOUS INJURY.

WARNING

THE USE OF THIS EQUIPMENT IN A MANNER NOT SPECIFIED IN THIS MANUAL OR BY THE MANUFACTURER MAY IMPAIR PROTECTION OF THE USER AND EQUIPMENT.

CAUTION

THIS EQUIPMENT IS DESIGNED FOR INSTALLATION IN AN ENCLOSURE THAT PROVIDES ADEQUATE PROTECTION AGAINST ELECTRICAL SHOCK.

1.6 UNPACKING

1.6.1 PHYSICAL DIMENSIONS

Product	Dimensions
HTR02-2AWS	45 x 99 x 117 mm
HTR02-6AWS(-PDD)	68 x 99 x 117 mm




Figure 9: Readers dimensions views

1.7 DIN RAIL MOUNTING

CAUTION

ENSURE THAT THE LOW-LEVEL COMPARTMENT WHERE THE READER IS MOUNTED IS SUFFICIENTLY VENTILATED TO PREVENT OVERHEATING. THE DEVICE MUST BE ELECTRICALLY GROUNDED FOR EMC COMPLIANCE.

The reader is designed for installation on a grounded 35 mm DIN rail. DIN rail fixation is integrated on its rear enclosure.




Figure 10: DIN rail fixation

1.7.1 READER EMPLACEMENT

The reader is intended to be installed in the low voltage compartment of the switchgear. The other electrical assets are recommended to be weather protected in an enclosed location.




Figure 11: Reader emplacement in switchgear

The reader is required to be installed within a maximum distance of *10 meters* from the antennas, corresponding to the maximum length of the antenna coaxial cable for SAW temperature sensors and partial discharge measurement.

1.7.2 RECOMMENDED SPACING

For connectors access, it is recommended to leave the minimum clearance for front and bottom panels of *5 cm (2 inches)*.



Figure 12: Reader access clearance

WIRING

1.8 POWER

The reader power connector is a 2-pin male connector. This screw connector supports from 16 to 26 AWG wires. For stranded conductor use connector ferrules on the termination.



Figure 13: Connector ferrule

1.8.1 INPUT POWER

The reader operates at 24VDC nominal with a total power consumption of 6 Watts maximum.

SENSeOR recommends the use of a **DC power supply** in the same low-voltage compartment as the reader. It is possible to run a DC power bus to power multiple readers from one DC power supply. However, this option requires a careful consideration of the wire diameter, AC/DC and circuit breaker capabilities.

Power connections are recommended to be at a minimum of 16 AWG.

If bussed power is being considered, the wire gauge must be selected to prevent excessive voltage drop between the DC power source and the reader that is electrically farthest from the source.

The following block diagram outlines the recommended power wiring for the reader with a 2-pole circuit breaker and an AC/DC power supply. Surge suppression devices can also be installed between the input line and the neutral only if higher safety rating is required.




Figure 14: Reader power cabling

1.8.2 INTERNAL BATTERY

SENSeOR reader has an internal 3VDC non rechargeable battery to keep the UTC date and the time in case of power down. Battery needs to be replaced if voltage value is under **2.7V**.

It can be replaced only by authorized person using the following or an equivalent reference:



Figure 15: 3V Lithium CR1632 battery

1.8.2.1 Battery replacement procedure

- ▶ Disconnect all the HTR02 reader connections (antennas, environmental sensor, analog I/Os and power supply).
- ▶ Extract the reader from its location on the DIN rail.
- ▶ Using a *flat* screwdriver, open the rear plastic enclosure by pressing the clips above and under the reader.
- ▶ Remove the electronic card from the rear enclosure.
- ▶ Identify and replace the CR1632 battery **by carefully respecting its polarity**.
- ▶ Reinsert the electronic card in the enclosure.
- ▶ Reclip the rear plastic enclosure.
- ▶ Reposition the reader on its location on the DIN rail.
- ▶ Reconnect all the HTR02 reader connections (antennas, environmental sensor, analog I/Os and power supply).

WARNING

THERE IS A RISK OF EXPLOSION IF THE BATTERY IS REPLACED BY AN INCORRECT TYPE.
BE CAREFUL OF USED BATTERY IN ACCORDANCE WITH YOUR REGIONAL LEGAL INSTRUCTIONS.

1.9 COMMUNICATION CONNECTIONS

The components are used to connect Modbus devices, energy communication systems and industrial equipment with each other and to SCADA or cloud systems.

The reader could be connected to a network using RS485 Modbus-RTU or Ethernet Modbus-TCP.

1.9.1 CABLING FOR RS485 COMMUNICATION

SENSeOR recommends the use of shielded cable for the RS485 wiring, providing at least one twisted pair, one single line, and a drain wire. Although, a typical recommended cable has two twisted pair. The twisted pair provides $DATA \pm$ signals to each reader while the single line would be for $D-COM$, providing a low-impedance return for each reader.




Figure 16: RS485 daisy chaining

1.9.2 BUS RESISTIVE TERMINATION

The RS485 bus needs to be terminated at each end with a 120 Ohms resistor when long stretches of cable are used. This ensures that the bus has the correct impedance.

However, if the bus length is less than 2% of its maximum (20 meters at 9 600 bauds), the termination resistor may be omitted.

In general, RS485 adapters and master bus provide the source impedance internally and should be located at one end of the bus. If not, use this pinout to cable the resistor.

Pin	Type	Description
1 (left)	-	Not used
2	-	Not used
3	-	Not used
4	120 Ohms	Resistance pin 1
5	120 Ohms	Resistance pin 2
6	-	Not used
7	-	Not used
8 (right)	-	Not used

1.9.3 BUS DATA RATE

The RS485 bus data rate is dependent on the bus cable length and the number of readers on the bus. In industrial environments, slower data communication rates are generally more reliable.

1.9.4 BUS LENGTH

Bus cable length has an impact on the overall data rates that can be achieved. A conservative rule for RS485 follows this equation:

$$\text{Baud rate} \times \text{cable length (m)} < 10 \times 10^6$$

A 9 600 bauds network would require a bus length less than $(10 \times 10^6 / 9\,600)$ equals to 1 042 meters (about 3 400 feet). This is perfectly adequate for most substation installations.

1.9.5 NUMBER OF READERS

The more readers on the RS485 bus there are, the weaker the baud rate is. Baud rate must be adjusted to accommodate the electrical characteristics depending on the circuit.

The following table provides an example of recommended baud rate following the number of readers:

Number of readers	Recommended baud rate
1	115 200
2	38 400
3	19 200
From 4 to 15	9 600

SENSeOR recommends to connect a maximum of 15 readers on a RS485 bus.

1.9.6 MODBUS-RTU DEFAULT CONFIGURATION

By default, the reader is configured with the following settings:

- Baud rate: **19 200**
- Data bits: **8**
- Parity: **Even**
- Stop bits: **1**

1.9.7 CABLING FOR ETHERNET COMMUNICATION

SENSeOR recommends the use of shielded *Cat 5e SFTP* cable for the Ethernet wiring.

Readers Ethernet network is provided by a fixed configuration more detailed below.

The IP address is defined by the last four digits of the product serial number printed on the side of the reader.

Serial number: 12345_67890

IP address: 10.200.78.90

The connected computer must have an IP address in the range of '10.200.AA.BB' subnet and with '255.255.0.0' mask. To avoid any IP addresses conflict between the reader and the computer, 'AA' and 'BB' settings are recommended to be higher or to be equal to the value of '100'.




Figure 17: Modbus-TCP cabling

WARNING

IN CASE OF COMMUNICATION TROUBLES WITH THE 'SENSeOR CONFIGURATION TOOL FOR HTR02' APPLICATION, CHECK THAT THE FOLLOWING COMMUNICATION PORTS ARE OPENED ON THE COMPUTER: '6560', '5706' & '5707'.

1.10 ENVIRONMENTAL SENSOR CONNECTION

The *SENSeOR* environmental sensor provides humidity, ambient temperature and dew point measurements recommended to complement the partial discharges data. Connection of this environmental sensor must be done respecting cable and connector positions.

Use 4-conductor 24 AWG shielded cable with 6-meter maximum length.




Figure 18: Environmental sensor cabling

SYSTEM INSTALLATION & CONFIGURATION

1.11 SAW TEMPERATURE SENSORS INSTALLATION

This manual does not cover all specific SAW temperature sensors installation.

1.12 SYSTEM CONFIGURATION

The reader requires a system configuration for the associated installed SAW temperature sensors, the ambient humidity and temperature sensors and the partial discharge probe antennas.

The configuration is performed through the Ethernet network interface and uses the '*SENSeOR Configuration Tool for HTR02*' application.

For configuration details, see the '[SENSeOR Configuration Tool for HTR02 User Manual](#)' for detailed instructions.

SYSTEM INTEGRATION

The HTR02 reader supports RS485 Modbus slave communication. It can be connected to an existing SCADA or PLC.

1.13 MODBUS REGISTERS

Description	Register address	Data type	Min. value	Max. value	Error value	Meaning	
INPUT REGISTERS (READ ONLY)							
SAW SENSOR TEMPERATURE DATA							
Group A (Antenna 1)	SAW ID 1 (A1)	30001	Signed	-500 (for °C)	1 800 (for °C)	-32 768	1/10°
	SAW ID 2 (A2)	30002					
	SAW ID 3 (A3)	30003					
Group B (Antenna 1)	SAW ID 4 (B1)	30004					
	SAW ID 5 (B2)	30005					
	SAW ID 6 (B3)	30006					
Group C (Antenna 2)	SAW ID 7 (C1)	30007					
	SAW ID 8 (C2)	30008					
	SAW ID 9 (C3)	30009					
Group D (Antenna 2)	SAW ID 10 (D1)	30010					
	SAW ID 11 (D2)	30011					
	SAW ID 12 (D3)	30012					
Group E (Antenna 3)	SAW ID 13 (E1)	30013					
	SAW ID 14 (E2)	30014					
	SAW ID 15 (E3)	30015					
Group F (Antenna 3)	SAW ID 16 (F1)	30016					
	SAW ID 17 (F2)	30017					
	SAW ID 18 (F3)	30018					
SAW SENSOR GROUP DATA							
Group A (Antenna 1)	Mean measurement	30019	Signed	-500	1 800	-32 768	1/10°
	Alarm status bit mask	30020	Unsigned	0	65 535	0	*see Table 1
Group B (Antenna 1)	Mean measurement	30022	Signed	-500	1 800	-32 768	1/10°
	Alarm status bit mask	30023	Unsigned	0	65 535	0	*see Table 1
Group C (Antenna 2)	Mean measurement	30025	Signed	-500	1 800	-32 768	1/10°
	Alarm status bit mask	30026	Unsigned	0	65 535	0	*see Table 1
Group D (Antenna 2)	Mean measurement	30028	Signed	-500	1 800	-32 768	1/10°
	Alarm status bit mask	30029	Unsigned	0	65 535	0	*see Table 1
Group E (Antenna 3)	Mean measurement	30031	Signed	-500	1 800	-32 768	1/10°
	Alarm status bit mask	30032	Unsigned	0	65 535	0	*see Table 1
Group F (Antenna 3)	Mean measurement	30034	Signed	-500	1 800	-32 768	1/10°
	Alarm status bit mask	30035	Unsigned	0	65 535	0	*see Table 1
ENVIRONMENTAL SENSOR DATA							

Ambient temperature		30037	Signed	-500	1 800	-32 768	1/10°	
Ambient humidity		30038	Unsigned	0	1 000	65 535	1/10 %rH	
Ambient dew point		30039	Signed	-500	1 800	-32 768	1/10°	
PARTIAL DISCHARGE DATA								
Probe antenna 1	Alarm status bit mask	31000	Unsigned	0	65 534	65 535	*see Table 2	
	LFB ratio	31001					1/10 dB	
	LFB EPPC	31002					1/10 peaks/cycle	
	MFB ratio	31004					1/10 dB	
	MFB EPPC	31005					1/10 peaks/cycle	
	HFB ratio	31007					1/10 dB	
	HFB EPPC	31008					1/10 peaks/cycle	
Probe antenna 2	Alarm status bit mask	31013					0	*see Table 2
	LFB ratio	31014					1/10 dB	
	LFB EPPC	31015					1/10 peaks/cycle	
	MFB ratio	31017					1/10 dB	
	MFB EPPC	31018					1/10 peaks/cycle	
	HFB ratio	31020					1/10 dB	
	HFB EPPC	31021					1/10 peaks/cycle	
Probe antenna 3	Alarm status bit mask	31026					0	*see Table 2
	LFB ratio	31027					1/10 dB	
	LFB EPPC	31028					1/10 peaks/cycle	
	MFB ratio	31030					1/10 dB	
	MFB EPPC	31031					1/10 peaks/cycle	
	HFB ratio	31033					1/10 dB	
	HFB EPPC	31034					1/10 peaks/cycle	
SYSTEM DATA								
Serial number		39001	String (10)	0	-	-	S/N	
Product vendor		39011	String (7)	-			SENSeOR	
Product model		39018	String (14)	-			*see Table 3	
Main board	Major HW revision	39032	Unsigned	0	65 535	-		
	Minor HW revision	39033						
	Major SW revision	39034						
	Minor SW revision	39035						
	Patch SW revision	39036						
PDD board	Major HW revision	39037					Default value: 65 535	
	Minor HW revision	39038						
	Major SW revision	39039						
	Minor SW revision	39040						
	Patch SW revision	39041						
Modbus table version	Major revision	39042	Default value: 1					
	Minor revision	39043	Default value: 2					
	Patch revision	39044	Default value: 0					

HOLDING REGISTERS (READ/WRITE)										
READER SETTINGS										
Modbus	Address	40001	Unsigned	1	247	65 535	Reader S/N + 1			
	Baud rate code	40002		0	7		*see Table 4			
	Parity code	40003		2	*see Table 5					
	Stop bits	40004		1	2		Default value: 1			
Temperature unit code		40005		1	*see Table 6					
Ethernet IP address	Byte 0	40006		0	255	-	Depend of S/N			
	Byte 1	40007					Depend of S/N			
	Byte 2	40008					Default value: 200			
	Byte 3	40009					Default value: 10			
Subnet mask	Byte 0	40010					Default value: 0			
	Byte 1	40011					Default value: 0			
	Byte 2	40012					Default value: 255			
	Byte 3	40013					Default value: 255			
Default gateway	Byte 0	40014					Default value: 1			
	Byte 1	40015					Default value: 0			
	Byte 2	40016					Default value: 200			
	Byte 3	40017					Default value: 10			
ALARM ACKNOWLEDGEMENTS										
Group A	Alarm acknowledgement	40101	Unsigned				0	65 535	-	To proceed: write the 65 535 value to the corresponding register. Alarm mechanisms keep memory of detected alarms. In case of alarm situation is still in progress, the alarms bit will not be removed.
Group B		40102								
Group C		40103								
Group D		40104								
Group E		40105								
Group F		40106								
PDD probe antenna 1		40107								
PDD probe antenna 2		40108								
PDD probe antenna 3		40109								

NOTE

FOR LEGACY MODBUS TABLES, PLEASE CONTACT THE SENSEOR SUPPORT
SUPPORT.SENSOR@WIKA.COM.

Table 1: Alarm register code

Bit number	Description
0	Sensor 1 overheating warning
1	Sensor 1 overheating alert
2	Sensor 1 deviation warning
3	Sensor 1 deviation alert
4	Sensor 1 RF link alert
5	Sensor 2 overheating warning
6	Sensor 2 overheating alert
7	Sensor 2 deviation warning
8	Sensor 2 deviation alert
9	Sensor 2 RF link alert
10	Sensor 3 overheating warning
11	Sensor 3 overheating alert
12	Sensor 3 deviation warning
13	Sensor 3 deviation alert
14	Sensor 3 RF link alert
15	Ambient temp. and humidity sensor alert

Table 2: Partial discharge probe antenna alarm register code

Bit number	Description
0	Probe antenna LFB Ratio warning
1	Probe antenna LFB Ratio alert
2	Probe antenna LFB EPPC warning
3	Probe antenna LFB EPPC alert
4	Probe antenna MFB Ratio warning
5	Probe antenna MFB Ratio alert
6	Probe antenna MFB EPPC warning
7	Probe antenna MFB EPPC alert
8	Probe antenna HFB Ratio warning
9	Probe antenna HFB Ratio alert
10	Probe antenna HFB EPPC warning
11	Probe antenna HFB EPPC alert
12	<i>Not used</i>
13	<i>Not used</i>
14	<i>Not used</i>
15	<i>Not used</i>

Table 3: Reader product register code

Model	Description
HTR02-2AWS	Temperature monitoring only
HTR02-6AWS	Temperature monitoring only
HTR02-6AWS-PDD	Temperature & partial discharge monitoring

Table 4: Modbus baud rate register code

Register value	Baud rate (bps)
0	9 600
1	14 400
2	19 200 (default value)
3	28 800
4	38 400
5	57 600
6	115 200
7	230 400

Table 5: Modbus parity register code

Register value	Parity
0	None
1	Odd
2	Even (default value)

Table 6: System temperature unit register code

Register value	Configuration
0	Celsius (default value)
1	Fahrenheit

CERTIFICATIONS

1.14 CERTIFICATIONS

RoHS 2011/65/EU and 2015/863/EU

IEC 62271-1: Switchgear, CISPR11

IEC 61000-4-2, IEC 61000-4-4, IEC 61000-4-17

IEC 61000-4-18, IEC 61000-4-29


IEC 60068-2-1, IEC 60068-2-2, IEC 60068-2-6, IEC 60068-2-30

IEC 60068-2-6, IEC 60068-2-78

IEC 60255-21-1, IEC 60255-21-3

IEC 61010-1

CEPRI-EETC06-2019-0023 / CCAM19LP1860T6



1.15 MARKING

File number: E510280 – Measuring Equipment

